

Download Instructions Manual For Spoa10 Rotary Lift Installation

For SPOA10 Extra Narrow Bay Setting installation, see step 7b, all others go to step 7c. 7b. For Extra Narrow Bay installation only: Cut off 11" from the length of the bar and cushion on the end opposite the 1/4" mounting hole(s). Continue to step 7c. 7c. Continued Overhead Assembly: For single phase and three phase lifts with push buttonFor SPOA10 Extra Narrow Bay Setting installation, see step 7b, all others go to step 7c. 7b. For Extra Narrow Bay installation only: Cut off 11" from the length of the bar and cushion on the end opposite the 1/4" mounting hole(s). Continue to step 7c. 7c. Continued Overhead Assembly: For single phase lifts: Insert 1/4"-20NC x 2-3/4" HHCSINSTRUCTIONS or if it has broken or damaged parts. Use only INSTRUCTIONS qualified lift service personnel and genuine Rotary parts to make repairs. • Thoroughly train all employees in use and care of lift, using manufacturer's instructions and "Lifting It Right"...SPOA10: ARO14: RLP77: SL210: Get the job done faster! Dramatically accelerate productivity at your shop with Shockwave, a combination of technologies for Rotary 2-post lifts and inground SmartLifts ... Technical drawings, product manuals, the documents you never look at.